

Self-adjusting Cutter-stripper



Wire Cutting Function






Place cable between cutter and 2. Clamp prepared cablebetween 3. Press on handles, cable is locked blades (1) and close handles front blades (2) for the length to by external jaws while the be stripped, using as reference millimeter scales (3) laterally



insulation is lightly cut without damaging the conductor(s). For cables with particular soft or very hard sheath changed blade pressure using the adjustment(4)



The complete closing of the 5. Ve y soft or slippery cables should handles operates a sliding action of the blades that remove the

